

Everything you need to know about Industrial Tunnel Type Food Products Medicine Products Microwave Sterilizer In 2024

Detail Introduction :

Introduction

Working principle

Key components of industrial microwave ovens

Comparison and advantages of microwave technology and traditional sterilization methods

Technical parameters

Application of industrial tunnel food and drug microwave sterilizers

Technological progress and innovation of industrial tunnel food and drug microwave sterilizers


Precautions for the selection and implementation of industrial tunnel food and drug microwave sterilizers

Post-maintenance guide

References

Introduction

In 2024, the Industrial Tunnel Type Microwave Sterilizer stands as a pinnacle of technological advancement in the sterilization of food and medicine products. Utilizing microwave technology, this sterilizer offers unparalleled efficiency and effectiveness in eliminating harmful pathogens while preserving the quality and integrity of the products. As we delve into the intricacies of this innovative sterilization method, it becomes evident that its application extends far beyond conventional techniques, shaping the landscape of food and medicine safety in the modern era.




Working principle

In 2024, [Industrial Tunnel Type Food Products Medicine Products Microwave Sterilizers](#) represent the pinnacle in modern sterilization technology. Understanding their working principle is crucial for grasping their significance in various industries.

At its core, the working principle of Industrial Tunnel Type Microwave Sterilizers revolves around the utilization of microwave radiation for sterilization purposes. Unlike traditional sterilization methods that rely on heat or chemicals, microwave sterilization operates by exposing the target product to electromagnetic waves at specific frequencies.

These electromagnetic waves penetrate the product, causing the water molecules within to vibrate rapidly, generating heat. This heat effectively kills microorganisms present in the product, ensuring safety and extending its shelf life. Moreover, the non-ionizing nature of microwave radiation causes no alterations to the product's chemical composition or nutritional content, preserving its quality. Industrial Tunnel Type Microwave Sterilizers are particularly adept at sterilizing food and medicine products due to their ability to penetrate deeply into dense materials, ensuring thorough and uniform sterilization. The tunnel-type design allows for continuous processing of large volumes of product, making them ideal for industrial-scale production.

Furthermore, the flexibility of microwave sterilization enables the treatment of a wide range of products, including packaged and unpackaged items, without the need for preheating or post-cooling. This versatility not only enhances efficiency but also minimizes energy consumption and processing time.



Key components of industrial microwave ovens

Component	Description
Magnetron	The magnetron is the heart of the microwave oven, generating the microwaves used for heating and sterilization. It converts electrical energy into electromagnetic waves.
Waveguide	The waveguide is a metal tube that directs the microwaves from the magnetron into the oven cavity, ensuring efficient transmission of energy.
Stirrer Fan	The stirrer fan is responsible for distributing microwaves evenly throughout the oven cavity, preventing hot spots and ensuring uniform heating.
Control Panel	The control panel houses the interface used by operators to set the desired power levels, time settings, and other operating parameters.
Temperature Sensors	Temperature sensors monitor the internal temperature of the oven cavity, providing feedback for precise control of the sterilization process.
Safety Interlocks	Safety interlocks are mechanisms that prevent the oven from operating when the door is open, ensuring operator safety.
Cooling System	The cooling system consists of fans and vents that dissipate heat generated during operation, preventing overheating of components.
Conveyor System	In tunnel-type industrial microwave ovens, a conveyor system moves food and medicine products through the oven cavity, ensuring uniform exposure to microwaves.



Comparison and advantages of microwave technology traditional sterilization methods

Criteria	Microwave Sterilization	Traditional Sterilization
Sterilization Time	Short	Longer
Temperature Control	Precise	Limited
Energy Consumption	Lower	Higher
Uniformity of Sterilization	High	Variable
Nutrient Retention	Better	Reduced
Operating Cost	Moderate	High
Space Requirement	Compact	Larger
Environmental Impact	Lower	Higher

Technical parameters

Technical Parameters Of Continuous Microwave Dryer Industrial Microwave Dryer Machine					
Model	Size LWH(Can be customized according to the customer's requirements)	Output power	Dewaterability	Sterilization capacity	Baking capacity (Depends on different raw materials)
LY-10KW	5000mm825mm1750mm	?10KW	10KG/Hour	100KG/Hour	30-50KG/Hour
LY-20KW	8000mm825mm1750mm	?20KW	20KG/Hour	200KG/Hour	60-100KG/Hour
LY-30KW	8500mm1160mm1750mm	?30KW	30KG/Hour	300KG/Hour	90-150KG/Hour
LY-40KW	10000mm1160mm1750mm	?40KW	40KG/Hour	400KG/Hour	120-200KG/Hour
LY-50KW	12500mm1160mm1750mm	?50KW	50KG/Hour	500KG/Hour	150-250KG/Hour
LY-60KW	13500mm1450mm1750mm	?60KW	60KG/Hour	600KG/Hour	180-300KG/Hour
LY-70KW	13500mm1500mm1750mm	?70KW	70KG/Hour	700KG/Hour	210-350KG/Hour
LY-80KW	13500mm1650mm1750mm	?80KW	80KG/Hour	800KG/Hour	240-400KG/Hour
LY-100KW	16800mm1650mm1750mm	?100KW	100KG/Hour	1000KG/Hour	300-500KG/Hour
LY-150KW	22400mm1850mm1750mm	?150KW	150KG/Hour	1500KG/Hour	450-750KG/Hour
LY-200KW	27000mm1850mm1750mm	?250KW	250KG/Hour	2500KG/Hour	750-1250KG/Hour
LY-300KW	32000mm1850mm1750mm	?300KW	300KG/Hour	3000KG/Hour	900-1500KG/Hour
Power Supply		380V±10% 50Hz±1% Three-Phase Five-Wire			
Microwave Output Frequency		2450±50Mhz			

Microwave Input Apparent Power	?168Kva
Microwave Output Power	?120Kw
Microwave Power Adjustment Range	0-30Kw(Adjustable)
Ambient Temperature	-5-40°C
Relative Humidity	?80%, Surrounding Environment:No Corrosive Gas, Conductive Dust And Explosive Gas
Transmission Speed	0-10m/Min(Adjustable)



Application of industrial tunnel food and drug microwave sterilizers

In 2024, the application of [Industrial Tunnel Type Food Products Medicine Products Microwave Sterilizers](#) marks a significant advancement in the sterilization processes of food and drug industries. These sterilizers utilize microwave technology to effectively eliminate harmful microorganisms from food and medicine products, ensuring their safety and quality.

Industrial Tunnel Type Food Products Medicine Products Microwave Sterilizers employ a tunnel structure where food and medicine products pass through on a conveyor belt, exposing them to controlled microwave radiation. This method allows for efficient and uniform sterilization without compromising the integrity or quality of the products.

One key advantage of Industrial Tunnel Type Microwave Sterilizers is their ability to achieve sterilization while preserving the nutritional value and sensory characteristics of food and medicine products. Unlike traditional sterilization methods that may require prolonged exposure to high temperatures, microwave sterilization offers a quicker and more energy-efficient alternative. Moreover, Industrial Tunnel Type Microwave Sterilizers are highly versatile and can accommodate a wide range of food and medicine products, including packaged goods, liquids, and powders. T

versatility makes them suitable for various applications across the food and pharmaceutical industries, from sterilizing packaged meals to ensuring the safety of medical supplies.

In addition to their effectiveness and versatility, Industrial Tunnel Type Microwave Sterilizers offer advantages in terms of cost-effectiveness and environmental sustainability. By reducing the need for chemical preservatives and minimizing energy consumption, these sterilizers contribute to the overall efficiency and sustainability of food and drug production processes.

Overall, the application of Industrial Tunnel Type Food Products Medicine Products Microwave Sterilizers in 2024 represents a significant advancement in sterilization technology. With their ability to achieve rapid, uniform, and efficient sterilization while preserving product quality, these sterilizers play a crucial role in ensuring the safety and integrity of food and medicine products for consumers worldwide.

DETAIL CHARACTERISTICS

01 ENVIRONMENTAL POLLUTION-FREE
Microwave drying equipment does not produce environment of high temperature, dust and noise, without waste water and exhaust gas in the process of operation, no waste is generated.

02 HEATING UNIFORMITY
Material can generate heat at the same time under the action of electromagnetic waves from microwave, there will be no cake endogenous phenomenon.

03 ADVANCED TECHNOLOGY EASY TO CONTROL
Microwave heating just have the basic conditions of water, electricity, as long as control power of microwave which can realize the automatic control of heating process immediately.

04 SMALL FOOTPRINT SAFE AND HARMLESS
Because the microwave energy is control in metal heating indoor and work in the waveguide tube, so rarely microwave leak, no radiation damage and harmful gas emissions, and does not produce waste heat and dust pollution.

Technological progress and innovation of industrial tunnel type food and drug microwave sterilizers

In 2024, Industrial Tunnel Type Food Products Medicine Products Microwave Sterilizers represent the pinnacle of technological innovation in the sterilization industry. These advanced microwave sterilizers are specifically designed to meet the stringent requirements of sterilizing food and medicine products efficiently and effectively.

Industrial Tunnel Type Microwave Sterilizers utilize microwave radiation to eliminate harmful bacteria, viruses, and other pathogens from food and medicine products. Unlike conventional sterilization methods that rely on heat or chemicals, microwave sterilization offers rapid and uniform heating, ensuring thorough sterilization while preserving the quality and nutritional value of the products.


One key advantage of Industrial Tunnel Type Microwave Sterilizers is their versatility. They can accommodate a wide range of food and medicine products, including packaged goods, bulk materials,

and liquid formulations. This flexibility makes them suitable for various industries, from food processing plants to pharmaceutical manufacturing facilities.

Furthermore, Industrial Tunnel Type Microwave Sterilizers are equipped with advanced control systems that allow for precise adjustment of sterilization parameters, such as power level and exposure time. This ensures consistent and reliable sterilization results, meeting regulatory requirements and industry standards.

Additionally, Industrial Tunnel Type Microwave Sterilizers are designed with safety features that protect both the products being sterilized and the operators handling the equipment. These safety measures include automated shutdown systems, temperature monitoring sensors, and protective enclosures to prevent microwave leakage.

In summary, Industrial Tunnel Type Food Products Medicine Products Microwave Sterilizers represent a cutting-edge solution for sterilizing food and medicine products in 2024. Their technological innovation, versatility, and precision make them indispensable tools for ensuring product safety and quality in various industries.



Precautions for the selection and implementation of industrial tunnel food and drug microwave sterilizers

In 2024, Industrial Tunnel Type Food Products Medicine Products Microwave Sterilizer stands at the pinnacle of modern sterilization technology. This innovative equipment revolutionizes the food and pharmaceutical industries, ensuring the safety and quality of products for consumers worldwide. However, selecting and implementing these sterilizers requires careful consideration and adherence to certain precautions.

First and foremost, when selecting an Industrial Tunnel Type Food Products Medicine Products Microwave Sterilizer, it is essential to assess the specific needs and requirements of the production facility. Different types of food and drug products may have varying characteristics and susceptibilities to microwave sterilization.

to microbial contamination. Therefore, choosing a sterilizer with customizable settings and advanced features is crucial to achieving optimal sterilization results.


Additionally, it is imperative to verify the sterilizer's compliance with industry regulations and standards. Industrial sterilization processes for food and drug products are subject to stringent regulatory requirements to ensure product safety and efficacy. Selecting a sterilizer that meets or exceeds these standards is essential for regulatory compliance and consumer trust.

Furthermore, proper installation and maintenance of the Industrial Tunnel Type Food Products Medicine Products Microwave Sterilizer are paramount to its effectiveness and longevity. Installation should be conducted by trained professionals according to manufacturer guidelines to prevent malfunctions or safety hazards. Regular maintenance and calibration are also necessary to ensure consistent performance and avoid contamination risks.

Moreover, training and education of personnel involved in operating the sterilization equipment is essential for successful implementation. Proper handling of the sterilizer, including loading and unloading procedures, as well as troubleshooting common issues, can mitigate operational errors and maximize efficiency.

In conclusion, the selection and implementation of Industrial Tunnel Type Food Products Medicine Products Microwave Sterilizers require careful consideration of various factors, including product characteristics, regulatory compliance, installation, maintenance, and personnel training. By adhering to these precautions, manufacturers can effectively harness the power of microwave sterilization technology to ensure the safety and quality of food and drug products in 2024 and beyond.

LOYAL'S MICROWAVE ADVANTAGES



Post-maintenance guide

In 2024, Industrial Tunnel Type Food Products Medicine Products Microwave Sterilizer represents a cutting-edge solution for the sterilization of food and medicine products. This advanced equipment harnesses the power of microwave technology to eliminate harmful microorganisms and ensure the safety and quality of consumable goods. However, effective maintenance is crucial to maximizing

performance and longevity of Industrial Tunnel Type Microwave Sterilizers.

Routine Inspection and Cleaning

Regular inspection and cleaning are essential components of post-maintenance for Industrial Tunnel Type Microwave Sterilizers. Inspect all components, including the microwave chamber, conveyor belts, and ventilation systems, for signs of wear, damage, or debris accumulation. Clean surfaces thoroughly using approved cleaning agents and techniques to prevent contamination and maintain optimal sterilization conditions.

Calibration and Testing

Calibration and testing are critical aspects of post-maintenance for Industrial Tunnel Type Microwave Sterilizers to ensure accurate and consistent performance. Regularly calibrate temperature sensors, power settings, and other critical components according to manufacturer specifications. Conduct routine performance tests using biological indicators to verify the effectiveness of sterilization processes and make necessary adjustments as needed.

Component Replacement

Over time, certain components of Industrial Tunnel Type Microwave Sterilizers may wear out or become obsolete, compromising performance and safety. As part of post-maintenance procedures, regularly assess the condition of components such as magnetrons, waveguides, and seals. Replace worn or damaged parts promptly to avoid downtime and ensure uninterrupted operation.

Safety Compliance

Maintaining safety compliance is paramount in post-maintenance activities for Industrial Tunnel Type Microwave Sterilizers. Adhere to all relevant safety regulations and guidelines, including proper handling of hazardous materials, electrical safety protocols, and emergency procedures. Provide comprehensive training to personnel responsible for operating and maintaining the equipment to minimize risks and ensure safe operation.

Documentation and Record-Keeping

Thorough documentation and record-keeping are essential aspects of post-maintenance for Industrial Tunnel Type Microwave Sterilizers. Maintain detailed records of maintenance activities, including inspections, repairs, calibrations, and tests. Document any deviations from standard procedures and corrective actions taken to address issues promptly. These records not only facilitate regulatory compliance but also serve as valuable resources for troubleshooting and continuous improvement.



References

The following are five authoritative foreign literature websites in the field of industrial microwave

1. IEEE Xplore Digital Library

Website: [<https://ieeexplore.ieee.org/>]

2. ScienceDirect

Website: [<https://www.sciencedirect.com/>]

3. SpringerLink

Website: [<https://link.springer.com/>]

4. Wiley Online Library

Website: [<https://onlinelibrary.wiley.com/>]

5. PubMed

Website: [<https://pubmed.ncbi.nlm.nih.gov/>]